

**SOLVAY**

asking more from chemistry®

Determination of Tetrakis(hydroxymethyl) Phosphonium Sulfate (THPS) in Tolcide® PS Biocides

CODE 4-8776-01

QUANTITY	CONTENTS	CODE
120 mL	DSP Reagent, 10% Solution	4133-J
120 mL	*Borate Buffer Solution	*4135-J
120 mL	PSSA Reagent, 5% Solution	4134-J
30 mL	Starch Indicator Solution	4170WT-G
60 mL	Iodine Solution, 0.025N	6377-H
15 mL	Zinc Acetate, 2N	3843-E
1	Test Tube, plastic, 5-10-25 mL, w/cap	0715
3	Pipets, 1 mL, plastic	0354
1	Direct Reading Titrator, 0-100 Range	0381
1	Dispenser Cap	0601

*WARNING: Reagents marked with an * are considered to be potential health hazards. To view or print a Safety Data Sheet (SDS) for these reagents go to www.lamotte.com. Search for the four digit reagent code number listed on the reagent label, in the contents list or in the test procedures. Omit any letter that follows or precedes the four digit code number. For example, if the code is 4450WT-H, search 4450. To obtain a printed copy, contact LaMotte by email, phone or fax.

Emergency information for all LaMotte reagents is available from Chem-Tel (US, 1-800-255-3924) (International, call collect, 813-248-0585).

To order individual reagents or test kit components, use the specified code number.

INTERFERENCES: Hydrogen sulfide can interfere with the determination of THPS. Pretreatment with zinc acetate will remove the interference. Add 5 drops of *Zinc Acetate, 2N (3843) for every 100 ppm hydrogen sulfide present in a 50 mL sample. Filter off the white precipitate that forms and proceed with Steps 1-11 using the filtrate.

PROCEDURE

1. Fill the test tube (0715) to the 25 mL line with the sample to be tested.
2. For fresh water samples, use a 1 mL pipet (0354) to add 2.0 mL DSP Reagent, 10% Solution (4133). For saltwater samples, use a 1mL pipet (0354) to add 2.0 mL *Borate Buffer Solution (4135).
3. Use another 1 mL pipet (0354) to add 2.0 mL of PSSA Reagent, 5% Solution (4134). Swirl to mix.
4. Add 6 drops of Starch Indicator Solution (4170WT). Swirl to mix.
5. Replace the regular cap on the bottle of Iodine Solution, 0.025N (6377) with the special dispenser cap (0601).
NOTE: Replace the regular cap on the Iodine Solution 0.025N bottle for storage.
6. Fill the Direct Reading Titrator (0381) with the Iodine Solution, 0.025N (6377).
7. Slowly add Iodine Solution, 0.025N (6377) to the test tube by depressing the plunger. Swirl the test tube after each drop to mix reagents.
8. Continue adding Iodine Solution, 0.025N (6377) until 1 drop results in a pale blue color that lasts 20 seconds.
9. Read the concentration (in ppm) of THPS directly from the scale where the large ring on the Titrator meets the Titrator barrel.
NOTE: Read the test result where the large ring on the Titrator meets the Titrator barrel. Each small division is equal to 2 ppm.
10. Repeat Steps 1-9 on a blank (system water without biocide) to determine background levels.
11. Subtract the blank reading from the reacted sample reading to determine the concentration of THPS in the sample.

NOTE: This test measures ppm active THPS. To obtain ppm of formulation, divide ppm THPS by the activity (in percent) of the formulation, and multiply by 100.

LaMOTTE COMPANY

Helping People Solve Analytical Challenges

PO Box 329 · Chestertown · Maryland · 21620 · USA
800-344-3100 · 410-778-3100 [Outside U.S.A.] · Fax 410-778-6394
Visit us on the web at www.lamotte.com