

# visocolor<sup>®</sup>HE

## Calcium CA 20

Test kit for the determination of residual hardness in soft water

## Method:

## Complexometric titration

Contents of test kit (\*refill pack):

sufficient for 200 tests with an average hardness of 10 °d

25 mL CA 20-1

- 10 mL CA 20-2\*
- 100 mL CA 20-TL\*
- 1 test tube with ring mark
  - 1 titration syringe 0-20 °d resp. 0-3.6 mmol/L

  - 2 plastic dropping tips

## Hazard warning:

Test kit contains sodium hydroxide solution 10-20%, the indicator solution contains ethanol 35-55 % and triethanolamine 10-20 %.

H314 Causes severe skin burns and eye damage. P260sh, P280sh, P303+361+353, P305+351+338, P310 Do not breathe dust/vapors. Wear protective gloves/eye protection. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water for shower], IF IN EYES: Rinse cautiously with water for several minutes Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER/doctor.

#### Procedure:

- 1 Rinse test tube several times with the test sample and fill to ring mark.
- 2. Add 2 drops CA 20-1 and shake. The test sample can get turbid.
- Add 2 drops CA 20-2 and shake. The test sample turns red. If sample turns blue, no calcium 3 is present (0 °d).
- Put dropping tip onto the titration syringe, press down plunger, dip the tip into the titration 4 solution CA 20-TL and draw up plunger slowly, until the lower rim of the black plunger O-ring agrees with value 0 on the barrel scale. The small air pocket below the plun-ger tip does not disturb the determination.
- Addition of the titration solution: We recommend taking the syringe in the left hand and the 5 test tube in the right hand (see drawing) and adding titration solution dropwise while smoothly shaking the test tube. As soon as the red color turns lighter, drop more slowly until the solution turns completely blue. If the test solution turns grey after 15-30 s, add dropwise titration solution CA 20-TL until color change repeats to blue

Read off calcium hardness in od or mmol/L from the syringe barrel (lower rim of the black plunger O-ring). Color change is followed easily when holding test tube before a light background (e.g. sheet of white paper).

If the first syringe filling isn't enough to reach color change (calcium hardness > 20 °d), fill sy-6 ringe once more with titration solution CA 20-TL and titrate to color change (as above). Read off calcium hardness and add for each used syringe filling 20 °d.

°d	°e	°f	mg/L CaO	mg/L CaCO₃	mmol/L H+
1	1.3	1.8	10	18	0.36
2	2.5	3.6	20	36	0.71
3	3.8	5.4	30	54	1.07
4	5.0	7.1	40	71	1.43
5	6.3	8.9	50	89	1.78
6	7.5	10.7	60	107	2.14
7	8.8	12.5	70	125	2.50
8	10.0	14.3	80	143	2.86
9	11.3	16.1	90	161	3.21
10	12.5	17.8	100	178	3.57

This method can be applied also for the analysis of sea water after dilution (1+4) and using 6 drops of sodium hydroxide solution.

Disposing of the samples:

The used analysis specimens can be flushed down the drain with tap water and channelled off to the local sewage treatment works.

## Remark:

The magnesium content is the difference between total hardness (VISOCOLOR® HE Total Hardness H 20 F, REF 915005) and calcium hardness.