



## CYANIDE KIT

Octa-Slide 2, 0-0.4 ppm

CODE 7387-02

QUANTITY	CONTENTS	CODE
60 mL	Cyanide Buffer	2850PS-H
5 g	*Cyanide Cl Reagent	*2794DS-C
5 g	Cyanide Indicator Reagent	2793DS-C
15 mL	*Hydrochloric Acid, 1N	*6130-E
15 mL	*Sodium Hydroxide, 1N	*4004-E
2	Test tubes, 2.5-5.0-10 mL, glass, w/caps	0844
2	Spoons, 0.05 g, plastic	0696
1	Pipet, 0.5 mL, plastic	0353
1	pH Short Range Test Paper, pH 6.5 - 13	2944
1	Stirring Rod, plastic	0519
1	Cyanide Octa-Slide 2 Bar, 0-0.4 ppm	4417-01
1	Octa-Slide 2 Viewer	1101


**\*WARNING:** Reagents marked with an \* are considered to be potential health hazards. To view or print a Safety Data Sheet (SDS) for these reagents go to [www.lamotte.com](http://www.lamotte.com). Search for the four digit reagent code number listed on the reagent label, in the contents list or in the test procedures. Omit any letter that follows or precedes the four digit code number. For example, if the code is 4450WT-H, search 4450. To obtain a printed copy, contact LaMotte by email, phone or fax.

Emergency information for all LaMotte reagents is available from Chem-Tel: (US, 1-800-255-3924) (International, call collect, 813-248-0585).

To order individual reagents or test kit components, use the specified code number.

Warning! This set contains chemicals that may be harmful if misused. Read cautions on individual containers carefully. Not to be used by children except under adult supervision.

### USE OF THE OCTA-SLIDE 2 VIEWER



The Octa-Slide 2 Viewer should be held so non-direct light enters through the back of the Viewer. Insert the Octa-Slide 2 Bar into the Viewer. Insert the reacted sample into the top of the Viewer. Match the color of the reaction to the color standards.

## PROCEDURE

---

1. Insert Cyanide Octa-Slide 2 Bar (4417-01) into Octa-Slide 2 Viewer (1101).
2. Fill test tube (0844) to 5 mL line with sample water.
3. Dip the end of the plastic rod (0519) into sample water. Touch to a small piece of Test Paper (2944) to wet paper. Immediately read pH from color chart. If pH is below 10, add \*Sodium Hydroxide, 1N (4004) one drop at a time until pH is between 10.5 and 11.0. Check pH with a piece of Test Paper (2944) after adding each drop. If pH is above 11.5, lower pH by adding \*Hydrochloric Acid, 1N (6130) one drop at a time until pH is between 10.5 and 11.0. Check pH with a piece of Test Paper (2944) after adding each drop.
4. Use the 0.5 mL pipet (0353) to add 0.5 mL of Cyanide Buffer (2850PS). Cap and invert 10 times to mix. Wait 30 seconds.
5. Use a 0.05 g spoon (0696) to add one measure of \*Cyanide Cl Reagent (2794DS). Cap and invert 10 times to mix. Wait 30 seconds.
6. Use a second 0.05 g spoon to add one measure of Cyanide Indicator Reagent (2793DS). Cap and shake vigorously for 15-20 seconds. Wait 20 minutes. Solution will turn violet if cyanide is present.
7. Insert test tube into Octa-Slide 2 Viewer.
8. Match sample color to a color standard. Record as ppm Cyanide.

### **LaMOTTE COMPANY**

Helping People Solve Analytical Challenges

PO Box 329 · Chestertown · Maryland · 21620 · USA  
800-344-3100 · 410-778-3100 [Outside U.S.A.] · Fax 410-778-6394

Visit us on the web at [www.lamotte.com](http://www.lamotte.com)